

Using the Video Projector



1. TURN ON VIDEO PROJECTOR. Turn off when finished.

- a. **Note:** Input source buttons WILL NOT work until the "ON" button stops flashing.

2. SELECT THE INPUT SOURCE YOU WISH TO DISPLAY.

3. VOLUME CONTROL

4. ADDITIONAL PROJECTOR CONTROLS

- a. **MUTE** - Removes projected image from screen (Does not turn off projector).
 - i. Button blinks red when activated; press again to deactivate.
 - ii. This projector may have a MUTE timeout that causes the image to reappear after 20 minutes.
- b. **FREEZE ON** - freezes image on screen. Blinks red when active; press again to deactivate.
- c. **AUTO IMAGE** - centers image.